

Quantification of functional IL-2 using iLite® IL-2 Assay Ready Cells

For research and professional use only. Not for use in diagnostic procedures.

This application note contains a suggested protocol and performance data. Each individual laboratory must set up their own method and perform relevant validations.

Background

Interleukin-2 (IL-2) is part of the body's natural response to microbial infection and a tool in the immune system discrimination between foreign ("non-self") and "self". It signals through the IL-2 receptor, a complex consisting of three chains, termed alpha, beta, and gamma.

IL-2 has essential roles in key functions of the immune system, tolerance and immunity, primarily as a stimulant of T- and B-cell growth and maturation. IL-2 activates and stimulates the growth of immune cells, most importantly T-Cells, but also Natural Killer Cells (NK Cells), both can eliminate cancer cells directly. Anti-tumor effects of IL-2 appear to be mediated by its effects on NK Cells, Lymphokine-activated Killer Cells and other cytotoxic cells (1,2).

Principle of the assay

The $iLite^{\circledast}$ IL-2 Assay Ready Cells are engineered cells, optimized to express Firefly luciferase (FL) under the control of an IL-2 responsive promoter. Binding of IL-2 to the IL-2 receptor (IL-2R α , IL-2R β , and IL-2R γ) results in activation of the IL-2 regulated Firefly luciferase reporter gene construct. $iLite^{\circledast}$ IL-2 Assay Ready Cells also contain the Renilla Luciferase (RL) reporter gene, under the control of a constitutive promoter. The constitutive expression of RL allows normalization of IL-2 induced FL activity, and renders assay results independent of variations in cell number or serum matrix effects. The luciferase signal can be measured in a luminometer following addition and incubation of luciferase substrate. The Firefly luciferase signal is proportional to the concentration of functional IL-2 in a sample (Fig.1).

Specimen collection

The *iLite*[®] IL-2 Assay Ready Cells can be used for measuring concentration of IL-2 in test samples including human serum.

Material and equipment needed

Material and equipment	Suggested supplier	Reference
iLite® IL-2 Assay Ready Cells	Svar Life Science	BM4002
Diluent (RPMI containing 9% heat inactivated FBS + 1% Penicillin-Streptomycin)	Gibco	61870-044 (RPMI) 26140-079 (FBS) 15140-122 (Penicillin- Streptomycin)
IL-2 or analogues	Immunotools	11340025
Firefly/Renilla luciferase substrate	Promega	E2920, Dual-Glo Luciferase Assay System
Plate; White walled micro well plate suitable for luminescence	Revvity	6055680
Microplate Luminometer with appropriate reading software – no filter on luminometer	Contact Svar Life Science for list of recommended suppliers	NA

APPLICATION NOTE




Incubator, 37 °C with 5% CO ₂	NA	NA
Water bath, 37 °C	NA	NA
Single-channel and multi-channel pipettes with polypropylene disposable tips	NA	NA
Polypropylene tubes or plate for dilution	NA	NA
Single-use polypropylene reservoir	NA	NA
Plate shaker	NA	NA
Timer	NA	NA

Protocol

Preparation of calibrators (IL-2)

Recombinant IL-2 from Immunotools has successfully been used to stimulate the *iLite*[®] IL-2 Assay Ready Cells. The below table shows the dilutions of IL-2, used for QC release of the *iLite*[®] IL-2 Assay Ready Cells.



	IL-2	
Calibrator	Suggested calibrator solution conc. (ng/ml)	
Α	3000	
В	750	
С	188	
D	47	
E	12	
F	2.9	
G	0.37	
Н	0	

Figure 1. Example of IL-2 calibration curve.

Table 1. Suggested calibrator **solution concentrations** for IL-2.

Incubation

- 1. Design a plate layout. It is recommended to perform the test at least in duplicates.
- 2. Dilute calibrators, controls and samples to fall within the expected **in assay values** of 0-1500 ng/mL.
- 3. Add 40 μ L calibrators, controls and samples in duplicate to assigned wells (final concentration will be half of solution concentration).
- 4. Thaw the vial of *iLite*® IL-2 Assay Ready Cells in a 37°C water bath with gentle agitation. The cell suspension is mixed very carefully ten times with pipette in order to ensure a homogeneous distribution of cells.
- 5. Dilute 250 µL cell suspension with 5.75 mL Diluent.
- 6. Add 40 µL diluted cells to each well.
- 7. Place the lid on the plate, mix and incubate for 5 hours at 37 °C with 5% CO₂.

Adding substrate solutions

- 8. Equilibrate the plate and the substrate solution to room temperature.
- 9. Prepare the **Firefly luciferase** substrate according to the supplier's instructions and add 80 μL per well. Mix and protect the plate from light. After 10 minutes incubation at room temperature read in a luminometer.

APPLICATION NOTE



10. If appropriate, prepare the **Renilla luciferase** substrate according to the supplier's instructions and add 80 μL per well. Mix and protect the plate from light. After 10 minutes incubation at room temperature read in a luminometer.

Precautions

- This application note is intended for professional laboratory research use only. The data and results originating from following the Application Note should not be used either in diagnostic procedures or in human therapeutic applications.
- Use and handle the material and instruments referenced according to the supplier's/manufacturer's instructions or product specifications accompanying the individual material and instruments.
- Dispose of all sample specimens, infected or potentially infected material in accordance with good microbiological practice. All such materials should be handled and disposed as though potentially infectious.
- Residues of chemicals and preparations are generally considered as biohazardous waste and should be inactivated prior to disposal by autoclaving or using bleach. All such materials should be disposed of in accordance with established safety procedures.

Proprietary Information

In accepting delivery of *iLite*[®] Assay Ready Cells the recipient agrees not to sub-culture these cells, attempt to sub-culture them or to give them to a third-party recipient, and only to use them directly in assays. *iLite*[®] cell-based products are covered by patents which are the property of Svar Life Science AB and any attempt to reproduce the delivered *iLite*[®] Assay Ready Cells is an infringement of these patents.



QUICK GUIDE

Quantification of functional IL-2 using iLite® IL-2 Assay Ready Cells



- Equilibrate reagents and samples to room temperature do not thaw cells and substrate reagents at this stage
- · Dilute calibrators, controls and samples.
- Add 40 µL of calibrators, controls and diluted samples to pre-assigned wells.
- Thaw the cell vial in a 37°C water bath. Mix the cell suspension with a pipette in order to ensure a homogeneous cell solution. Dilute the cells.
- Add 40 µL diluted cells to each well.

• Incubate at 37 °C with 5% CO₂ for 5 hours.

Incubation

5 h

3 Read plate

- Equilibrate the plate to room temperature
- Prepare the **Firefly luciferase** substrate according to the supplier's instructions and add 80 µL per well. Mix. Protect the plate from light. After 10 min incubation read in a luminometer.
- If appropriate, prepare the **Renilla luciferase** substrate according to the supplier's instructions and add 80 µL per well. Mix. Protect the plate from light. After 10 min incubation read in a luminometer.

Troubleshooting and FAQ

Please consult the Svar Life Science website www.svarlifescience.com

References

- 1. Liao W, Lin JX, Leonard WJ (October 2011). "IL-2 family cytokines: new insights into the complex roles of IL-2 as a broad regulator of T helper cell differentiation". Current Opinion in Immunology. 23 (5): 598–604.
- 2. Gaffen SL, Liu KD (November 2004). "Overview of interleukin-2 function, production and clinical applications". Cytokine. 28 (3): 109–23.