

Quantification of functional VEGF using *iLite*[®] VEGF Assay Ready Cells

For research and professional use only. Not for use in diagnostic procedures.

*This application note contains a suggested protocol and performance data.
Each individual laboratory must set up their own method and perform relevant validations.*

Background

Vascular Endothelial Growth Factor (VEGF) is a signalling protein which is involved in both normal vascular growth and pathological angiogenesis. Without angiogenesis, growth of solid tumors would be limited by oxygen and nutrient supply. Tumors which express VEGF can overcome this limitation and are thus able to grow and metastasize. For this reason, different anti-cancer therapies targeting VEGF have emerged, e.g. a humanized anti-VEGF antibody bevacizumab (Avastin[™], Genentech) is currently widely used as a first-line therapy for colorectal cancer (1,2).

Principle of the assay

The *iLite*[®] ADC VEGF Assay Ready Cells are engineered cells optimized to express Firefly luciferase under the control of a VEGF responsive promoter. Binding of VEGF to the VEGF receptor 2 (VEGFR2) results in activation of the VEGF regulated Firefly luciferase reporter gene construct. The Firefly luciferase signal can be measured in a luminometer following addition and incubation of luciferase substrate. The Firefly luciferase signal is proportional to the concentration of functional VEGF in the sample (Fig.1).

Specimen collection

The *iLite*[®] VEGF Assay Ready Cells can be used for measuring concentration of VEGF in test samples including human serum.

Material and equipment needed

Material and equipment	Suggested supplier	Reference
<i>iLite</i> [®] VEGF Assay Ready Cells	Svar Life Science	BM4021
Diluent (DMEM containing 9% heat inactivated FBS + 1% Penicillin-Streptomycin)	Gibco	31966-021 (DMEM) 26140-079 (FBS) 15140-122 (Penicillin-Streptomycin)
VEGF or analogues	Gibco	PHC9394
Firefly substrate	Promega	E2620, Bright-Glo Luciferase Assay System
Plate; White walled micro well plate suitable for luminescence	PerkinElmer	6005680
Microplate Luminometer with appropriate reading software – no filter on luminometer	Contact Svar Life Science for list of recommended suppliers	NA
Incubator, 37 °C with 5% CO ₂	NA	NA
Water bath, 37 °C	NA	NA
Single-channel and multi-channel pipettes with polypropylene disposable tips	NA	NA
Polypropylene tubes or plate for dilution	NA	NA

Single-use polypropylene reservoir	NA	NA
Plate shaker	NA	NA
Timer	NA	NA

Protocol

Preparation of calibrators (VEGF)

VEGF from Gibco has successfully been used to stimulate the *iLite*[®] VEGF Assay Ready Cells. The below table shows the dilutions of VEGF, used for QC release of the *iLite*[®] VEGF Assay Ready Cells.




Figure 1. Example of VEGF calibration curve.

Calibrator	VEGF
	Suggested solution calibrator conc. (ng/ml)
A	100
B	50
C	25
D	13
E	6.3
F	3.1
G	1.6
H	0

Table 1. Suggested calibrator **solution concentrations** for VEGF.

Incubation

1. Design a plate layout. It is recommended to perform the test at least in duplicate.
2. Dilute calibrators, controls and samples to fall within the expected **in assay values** of 0-50 ng/mL.
3. Add 40 μ L calibrators, controls and samples in duplicate to assigned wells.
4. Thaw the vial of *iLite*[®] VEGF Assay Ready Cells in a 37°C water bath with gentle agitation. The cell suspension is mixed very carefully ten times with pipette to ensure a homogeneous distribution of cells.
5. Dilute 250 μ L cells with 5.75 mL Diluent.
6. Add 40 μ L diluted cells to each well.
7. Place the lid on the plate, mix and incubate for 18 hours at 37 °C with 5% CO₂.

Adding substrate solutions

8. Equilibrate the plate and the substrate solution to room temperature.
9. Prepare the **Firefly luciferase** substrate according to the supplier's instructions and add 80 μ L per well. Mix and protect the plate from light. Read in a luminometer after 2 minutes incubation at room temperature.

Precautions


- This application note is intended for professional laboratory research use only. The data and results originating from following the Application Note should not be used either in diagnostic procedures or in human therapeutic applications.
- Use and handle the material and instruments referenced according to the supplier's/manufacturer's instructions or product specifications accompanying the individual material and instruments.
- Dispose of all sample specimens, infected or potentially infected material in accordance with good microbiological practice. All such materials should be handled and disposed as though potentially infectious.
- Residues of chemicals and preparations are generally considered as biohazardous waste and should be inactivated prior to disposal by autoclaving or using bleach. All such materials should be disposed of in accordance with established safety procedures.

Proprietary Information

In accepting delivery of *iLite*[®] Assay Ready Cells the recipient agrees not to sub-culture these cells, attempt to sub-culture them or to give them to a third-party recipient, and only to use them directly in assays. *iLite*[®] cell-based products are covered by patents which are the property of Svar Life Science AB and any attempt to reproduce the delivered *iLite*[®] Assay Ready Cells is an infringement of these patents

QUICK GUIDE

Quantification of functional VEGF using *iLite*[®] VEGF Assay Ready Cells



Troubleshooting and FAQ

Please consult the Svar Life Science website www.svarlifescience.com

References

1. **Wang Y, Fei D, Vanderlaan M, Song A.** *Biological activity of bevacizumab, a humanized anti-VEGF antibody in vitro.* *Angiogenesis* 7:335-345 (2004).
1. **Risau W.** *Mechanisms of angiogenesis.* *Nature* 386: 671-674 (1997).