FIBERTITE ROOFING SYSTEMS

By Seaman Corporation FTR-IW GS08/17 General Guide Specification for Installation Of FiberTite[®] Induction Welded Roofing Systems

PART 1 | GENERAL

1.1 SUMMARY

A. Scope

 Furnish and install a FiberTite® Induction Welded (IW) Roofing Systems as manufactured and supplied by: Seaman Corporation 1000 Venture Blvd. Wooster, Ohio 44691 Fax: (800)-649-2737

B. Special Conditions

- 1. This specification is applicable to only those building roofs that have decking of sufficient structural integrity, capable of supporting a FiberTite Induction Welded Roofing Systems.
- 2. All applications and project specifications require review by FiberTite Technical Customer Services (FTCS) for acceptance prior to any commitment to provide a commercial warranty.
- 3. Seaman Corporation FiberTite Pre-Installation Notice (FTR-PIN), must be completed, signed by an authorized roofing contractor, submitted to and approved by FTCS before any consideration for warranty and/or the release of any materials can be authorized.

C. Special Design Considerations

- 1. The building owner may be required to submit an engineering study, or Statement of Sound Roof Structure, to FTCS, indicating that the structure is able to accommodate additional live and/or dead loads including snow and water retention.
- 2. FiberTite Induction Welded Roofing Systems can be installed in conventional low slope or metal building recover applications.
- 3. All FiberTite Induction Welded Roofing Systems require an approved coverboard.
- 4. All FiberTite Roofing Membranes without fleece backing may be used for a Induction Welded Roofing System including FiberTite Brite.

D. Environmental Considerations

- 1. Severe environmental exposure (e.g. coastal or high wind area(s)).
- 2. Chemical discharge not listed on the Seaman Corporation/FiberTite chemical resistance publication.
- 3. Environmental conditions such as fog, dew, rain, snow and/or freezing temperatures can have a detrimental effect on the application and performance of adhesives.
- 4. Compliance with Environmental Protection Agency and OSHA requirements as published by local, state and federal authorities.

- 5. All adhesives can be described as temperamental at best. The contractor must be aware of all potential environmental variables when installing adhered roofing systems.
- 6. Pay particular attention to and follow all adhesive storage and application precautions/guidelines.
- 7. Do not apply/use waterborne adhesives (FTR-490) if the ambient air temperature is expected to drop below 32°F (0°C) within 72 hours of application.

1.2 FIBERTITE INDUCTION WELDED ROOFING SYSTEMS REFERENCES

- A. FiberTite General Guide Specification FTR GS08/17
- **B.** FiberTite Construction Details
- C. FiberTite Foreman's Manual
- D. Seaman Corporation Supplemental Best Practices for Induction Welded Installations
- E. FiberTite Technical Bulletins

1.3 QUALITY ASSURANCE

- A. FiberTite Induction Welded Roofing Systems shall be installed only by a roofing contractor, authorized by Seaman Corporation to install FiberTite Induction Welded Roofing Systems prior to bid and/or contract award. Herein, the term Authorized FiberTite Roofing Contractor is synonymous with authorized, roofing contractor and/or contractor.
- **B.** Roofing contractor's key personnel shall have received specialized training in the installation of FiberTite Roofing Systems and the OMG RhinoBond® and/or SFS isoweld® installation tools.
- **C.** FiberTite Induction Welded Roofing Systems shall be installed in accordance with the most current guide specifications (FTR IW GS07/15) and details as amended and/or authorized by FTCS for specific project requirements.
- **D.** There shall be no deviations from approved contract specifications or shop drawings without prior written approval by the owner/owner representative and FTCS.
- E. Unauthorized deviations may subject the roof system to warranty ineligibility.
- **F.** Any and all work found to be substandard or in violation of the Contract Documents or Manufacturer's Specifications shall be subject to rejection including complete removal and replacement with new materials at the expense of the Contractor.
- **G.** Upon completion, certification by the contractor that a quality installation has been completed in accordance with the approved contract specifications, and all field welds have been probed and inspected, a quality assurance inspection of the roof system shall be performed by FTCS for acceptance and approval.

1.4 SUBMITTALS

- A. The following information shall be submitted to FTCS for review before warranty consideration, material shipment or acceptance can be confirmed.
 - 1. Complete copy of project architectural specifications or roofing contractor's proposal outlining design parameters.
 - 2. Complete list of accessories or materials not manufactured or expressly authorized for use in FiberTite literature.
 - 3. Dimensioned outline of the roof indicating all FTR-Detail references.
 - 4. Dimensioned shop drawings illustrating non-FiberTite details. Details that do not conform with standard FiberTite details shall be returned with appropriate recommendations.
- **B.** At the time of contract award, the roofing contractor shall submit to the Owner/Owner's Representative the following:

- 1. Most recent published technical literature and guide specifications issued by FTCS. Roofing contractor's approved copy of submittal form FTR-PIN.
- 2. Dimensioned shop drawings, including roof plan detailing perimeter enhancement, flashing methods, terminations and acceptance by FTCS.
- **3.** Written approval from FTCS confirming any accessories submitted, not manufactured or expressly approved in FiberTite literature are acceptable and compatible with the proposed FiberTite Roofing System.
- 4. Material Safety Data Sheets (MSDS) relating to all products, chemicals and solvents.
- 5. Certification that the system specified complies with all identifiable building code and insurance requirements.

1.5 DELIVERY & STORAGE

- **A.** Deliver all materials to the job site in manufacturer's original, unopened containers, with legible labels and in sufficient quantity to allow for continuity of work.
- **B.** Select and operate material handling equipment in a safe manner, guarding against damage to existing construction or newly applied roofing and conforming to manufacturer's recommendations of handling and storage.
- **C.** All rolls of membrane shall be stored, lying down, elevated above the roof deck and completely protected from moisture with tarpaulins. Manufacturer's packaging is not considered adequate for outdoor storage.
- **D.** Insulation and cover board materials shall be elevated on pallets and fully protected from moisture with tarpaulins. Manufacturer's packaging is not considered adequate protection from moisture.
- E. Adhesives and sealants shall be safely stored between 50°F and 80°F prior to use.
- **F.** Flammable materials shall be stored in a cool, dry area away from sparks and open flames. Follow all precautions as outlined in manufacturer's Material Safety Data Sheets.
- **G.** Materials, having been determined by the owner/owner's representative to be damaged, shall be immediately removed from the construction site and replaced at no cost to the owner.

1.6 JOB CONDITIONS

- A. Safety
 - 1. Take all necessary precautions regarding worker health and safety when using solvents and adhesives.
 - 2. Worker safety is paramount when working on steep slopes.
 - 3. FiberTite is slippery when wet or exhibits dew, frost, ice are any other form of moisture.
 - 4. Comply with all OSHA requirements for steep slope construction and fall protection where required.
 - 5. Store flammable liquid and materials away from open sparks, flames and extreme heat.
 - 6. Take necessary precautions when using solvents and adhesives near fresh air intakes.
 - 7. Daily site cleanup shall be performed to minimize debris and hazardous congestion.

B. Protection

- 1. Schedule installation sequence to limit access and utilization of the newly installed membrane for material storage, construction staging, mechanical and/or excessive foot traffic.
- 2. Provide proper protection on all newly completed roofing to avoid damage to the new roofing system.

- 3. Traffic should be minimized on a freshly laid roof.
- 4. Protect building walls, rooftop units, windows and other components during installation.

C. Additional Precautions

- Adverse weather conditions (e.g. extreme temperature, high winds, high humidity and moisture) could have a detrimental effect on adhesives, general production efforts, and/or the quality of the finished installation. Contact FTCS for recommendations and acceptable tolerances.
- 2. Daily production schedules of new roofing shall be limited to only that which can be made 100% watertight at the end of the day, including all flashing and night seals.
- 3. All surfaces to receive new roof system, including insulation and flashing, shall be free from all dirt, debris and be thoroughly dry.
- 4. Comply with local EPA requirements as published by local, state and federal authorities.
- 5. All construction debris shall be removed from the construction site and legally disposed of offsite.

1.7 COORDINATION

- A. Prior to installation of materials, a pre-roofing conference shall be held with the roofing contractor, and owner/owner's representative to discuss the specified roofing system, coordinate its proper application and the expectations of all parties involved. The authorized roofing contractor and the owner/owner's representative shall notify all parties a minimum of 14 days prior to the meeting.
- **B.** Plan and coordinate the installation of the roofing system with other trades in such a manner to avoid membrane damage, keeping the complete installation weathertight and in accordance with all approved details and warranty requirements.
- **C.** FTCS shall be available to make recommendations necessary to ensure compliance with project specifications and specification alternatives due to unforeseen job conditions.
- **D.** Field services are provided at the discretion of Seaman Corporation. A minimum two weeks' notice is required to evaluate and coordinate any request for onsite technical assistance.

1.8 WARRANTY

A. Inspections

1. A FiberTite Technical Customer Service Representative shall inspect the completed FiberTite Induction Welded installation, and upon acceptance, Seaman Corporation shall issue the pre-authorized warranty, subject to the terms and conditions of the sample warranty and contract documents.

B. Available Warranties

- 1. Seaman Corporation offers the following FiberTite Induction Welded Roofing Systems warranties:
 - a. Material Warranty provides the building owner protection against the cost of repairing defects in the membrane only. This warranty is offered at no cost to the owner.
 - b. Standard Warranty provides the building owner protection against the cost of repairing leaks as a direct result of either defects in the membrane or the workmanship involved in its installation for a period of 10 years. There is a nominal premium.

c. Extended Warranty provides the building owner protection against the cost of repairing leaks as a direct result of either defects in the membrane or the workmanship involved in its installation beyond 10 years. There is an additional premium.

C. Maintenance

1. Along with the issuance of the warranty, a set of instructions shall be included detailing preventative maintenance requirements on the part of the building owner and noting a list of harmful substances that may damage the FiberTite Induction Welded Roofing System.

PART 2 | PRODUCTS

2.1 GENERAL

- A. All products and components for the FiberTite Induction Welded Roofing Systems shall be supplied by Seaman Corporation.
- **B.** Components other than those manufactured and/or supplied by Seaman Corporation shall be submitted for review, prior to ordering. Any product(s) not specifically authorized in writing for the project by Seaman Corporation, shall be considered unacceptable and their performance excluded from the warranty.
- **C.** FiberTite Induction Welded Roofing Systems may be installed directly over pre-approved insulation, cover board or composites thereof. Contact FTCS for additional information regarding compatible substrates.

2.2 MEMBRANE

- A. FiberTite Membrane FiberTite is a nominal 36 mil Ketone Ethylene Ester (KEE) membrane, reinforced with a 5.0 oz yd² knitted polyester fabric as manufactured by Seaman Corporation, under the trade name FiberTite, conforming to the physical properties as outlined in the associated data sheet. FiberTite exceeds all requirements outlined in ASTM D 6754 15 Standard Specification for Ketone Ethylene Ester (KEE) Sheet Roofing.
- B. FiberTite XT Membrane FiberTite XT is a nominal 50 mil Ketone Ethylene Ester (KEE) membrane, reinforced with a 6.5 oz yd² knitted polyester fabric as manufactured by Seaman Corporation, under the trade name FiberTite XT, conforming to the physical properties as outlined in the associated data sheet. FiberTite XT greatly exceeds all requirements outlined ASTM D 6754 15 Standard Specification for Ketone Ethylene Ester (KEE) Sheet Roofing.
- C. FiberTite SM Membrane FiberTite SM is a nominal 45 mil Ketone Ethylene Ester (KEE) membrane, reinforced with a 5.0 oz yd² knitted polyester fabric as manufactured by Seaman Corporation, under the trade name FiberTite SM, conforming to the physical properties as outlined in the associated data sheet. FiberTite SM exceeds the physical property requirements and the surface compound meets polymer content definitions as outlined in ASTM D 6754 15 Standard Specification for Ketone Ethylene Ester (KEE) Sheet Roofing.
- D. FiberTite XTreme Membrane FiberTite XTreme is a 60 mil Ketone Ethylene Ester (KEE), reinforced with a 12.5 oz yd² woven polyester mat, as manufactured by Seaman Corporation, under the trade name FiberTite XTreme, conforming to the physical properties as outlined in the associated data sheet. FiberTite XTreme greatly exceeds the physical property requirements and the surface compound meets polymer content definitions as outlined in ASTM D 6754 15 Standard Specification for Ketone Ethylene Ester (KEE) Sheet Membranes.
- **E.** Flashing Membrane Nominal 36 mil FiberTite, 45 mil FiberTite SM, 50 mil FiberTite XT or 60 mil FiberTite membrane shall be used for all respective roofing system flashing requirements to match the field membrane and warranty expectations selected for the roofing system.

F. Acceptable Substrate(s)

- 1. Authorized rigid insulation or cover board
- 2. Structural concrete; insulated
- 3. Insulated steel decking
- 4. Exterior grade plywood; insulated

2.3 RELATED MATERIALS "BY SEAMAN CORPORATION"

The following product(s)/material(s) shall be supplied by Seaman Corporation.

A. FTR Fasteners

- FiberTite MAGNUM Series To secure FiberTite membranes to steel, wood and structural concrete decks. A #15-13, buttress threaded, #3 Phillips head fastener constructed of case hardened carbon steel with a reduced diameter drill point and corrosion resistant coating.
- 2. FiberTite HD To secure insulation to steel, wood and structural concrete decks. A #14-13, heavy duty threaded steel #3 Phillips truss, self-tapping corrosion resistant fastener.

B. FTR Stress Plates

- 1. FTR IW RhinoBond® Plates- A 3" (75 mm) round, high-tensile, 22-gauge corrosion resistant steel plate with a KEE compatible polymeric coating used with approved fasteners to attach insulation boards to the structural deck and as a subsequent platform to induction weld the FiberTite Roofing Membrane.
- 2. FTR IW isoweld[®] Plates- A 3" (75 mm) round, high-tensile, 22-gauge corrosion resistant steel plate with a KEE compatible polymeric coating used with approved fasteners to attach insulation boards to the structural deck and as a subsequent platform to induction weld the FiberTite Roofing Membrane.
- 3. FTR-MAGNUM Series Barbed Stress Plates- When required/used to anchor membrane at roof transitions are 2.5" x 1.5" rectangular in dimension with ³/₄" radial corners, manufactured from 20-gauge AZ-50 galvalume steel with a 0.25" diameter hole in its center. The plate has a raised reinforcement area and eight barbs.

OR

Used to anchor membrane at roof transitions are 2.375" round steel plate manufactured from 20 gauge galvalume steel with a 0.25" diameter hole in its center. The plate has a raised reinforcement area and barbs.

C. FTR Adhesives

Adhesives, supplied by Seaman Corporation have been specially formulated for FiberTite Roofing Systems.

NOTE: Solvent-borne adhesives are not compatible with the FiberTite Brite Kynar Top-Finish or polystyrene insulations. Georgia-Pacific's DensDeck® Prime and/or USG's SECUROCK® or National Gypsum's DEXcell are the only approved cover-boards for use with FiberTite adhesives and subsequent adhered roofing systems. Application technique and coverage rates will vary according to substrate and environmental conditions.

1. FTR-190e Bonding Adhesive- A VOC compliant, solvent-borne, contact (two-sided) bonding adhesive, designed for bonding non-fleece back FiberTite membranes to properly prepared and pre-authorized horizontal and vertical substrates.

- 2. FTR #201 Mastic- A trowel grade elastomeric adhesive/sealant used to adhere FiberTite flashing membranes to preapproved vertical substrates.
- **3. FTR-490** Adhesive- A polymeric water-borne, VOC compliant bonding adhesive, used in contact method (substrate and membrane) for bonding FiberTite-SM membrane flashing to properly prepared and pre-authorized vertical substrates.

D. Additional Components

- 1. FTR-101 Sealant A one component gun-grade polyether sealant to seal flashing termination.
- 2. FiberClad Metal To fabricate metal flashing, 4' x 10' sheets of 24-gauge hot-dipped G-90 steel, or 0.040 mil thick 3003H14 aluminum, laminated with a 0.020 mil polymeric coating.
- 3. FTR Pre-Molded Flashing(s) Injection molded vent stack, split WrapidFlash[™] and inside/outside corner flashing using FiberTite KEE compound.
- 4. FTR Non-Reinforced Membrane Field fabrication membrane, 0.060 mil non-reinforced vinyl membrane.
- 5. FTR Tuff-Trac Walkway & Protection Pads High-grade walkway/protection material with slip-resistant design.
- 6. FTR Termination Bar Membrane flashing(s) restraint/termination seals, nominal 1/8" x 1" x 10' 6060-T5 extruded aluminum bar with pre-punched slots, 8" on center.
- 7. FTR Metal Fascia System Two-piece, snap-on, pre-formed, architectural Kynar fluoropolymer metal edge systems.
- 8. FTR-Value Insulation Polyisocyanurate and extruded polystyrene flat or tapered insulation.
- 9. FTR-601 Dual component, single-bead (ribbon applied) urethane insulation adhesive available in cartridges or pump grade. Adhesive is a non-solvent, elastomeric, urethane adhesive, specifically designed for bonding single or multiple layers of roof insulation and insulation composites and/or cover boards to structural roof decks and base sheets.
- **10. FTR-Cover Board** Gypsum or gypsum/cellulose core board.
- 11. FiberTite Seam Cleaner FiberTite Seam Cleaner is to be used with clean white cotton cloths/rags to clean contamination from the seam areas of the membrane prior to welding.
- 12. FTR-T-Joint Covers Pre-cut 4"x4" 60 mil non-reinforced membrane to reinforce areas where three overlapping sheets of membrane intersect.
- 13. VaporTite self adhered bitumen and SBS polymeric Class I Vapor Barrier

2.4 RELATED MATERIALS

A. Wood Nailers

- 1. Wood nailers are being tested to determine the effect preservatives on metal components. Borate treated lumber seem to be the less corrosive and is strongly recommended. Installation of other types of treated lumber should be verified with a design professional.
- 2. Wood shall be No. 2 or better construction grade lumber.
- 3. Creosote or asphaltic type preservatives are not acceptable.
- 4. Minimum top nailer thickness shall be $1\frac{1}{2}$ " nominal.
- B. Vapor Retarder

- 1. The use of a vapor retarder in a FiberTite Induction Welded Roofing Systems may require additional insulation attachment beyond the specified induction weld plates required for membrane attachment. Consult FTCS for guidelines.
- 2. The decision regarding the inclusion of a vapor retarder within the roof system shall fall within the responsibility of the design professional. Consult National Roofing Contractors Association (N.R.C.A.) or other technical resource for appropriate guidelines.
- 3. Vapor retarder for use in a roof system shall comply with identifiable code and/or insurance requirements.

C. Insulation

NOTE: For the purpose of this guide specification, unless explicitly defined otherwise, the term "insulation" is used interchangeably to refer to rigid insulation materials, tapered or flat, cover board, thermal barriers and or multilayered composites.

- 1. Insulation shall be installed, where specified and/or required to provide a suitable surface for the FiberTite Induction Welded Roofing Systems and/or meet desired thermal values.
- 2. Approved Products
 - i. FTR-Value Polyisocyanurate

FM approved rigid insulation meeting Class A 1-90, for fire and wind.UL Classification : Class A.Density: 2.0 pcf. MinimumMeet requirements of ASTM C1289

 ii. Gypsum Core Cover Board FM approved meeting Class A 1-90, for fire and wind. UL Classification: Class A Assembly. Meet requirements of ASTM C 473 Georgia-Pacific's DensDeck Prime National Gypsum DEXcell USG Securock

PART 3 | EXECUTION

3.1 GENERAL

- A. The authorized roofing contractor shall ensure strict compliance with FTR IW GS07/15; General Guide Specifications for Installation of FiberTite Induction Welded Roofing Systems.
- **B.** The roofing contractor shall provide a suitable substrate surface for the proper installation of the FiberTite Induction Welded Roofing Systems, roof insulation and specified components.
- **C.** Application of Seaman Corporation/FiberTite materials constitutes an agreement that the roofing contractor has inspected and found the substrate suitable for the installation of the FiberTite Brite Roofing System.
- **D.** The roofing contractor shall coordinate the installation to ensure that the system remains watertight at the end of each working day

3.2 SUBSTRATE PREPARATION

- **A.** The roofing contractor shall verifying that the deck condition and/or existing roof construction is suitable for the specified installation of the FiberTite Induction Welded Roofing Systems.
- **B.** Seaman Corporation requires fastener withdrawal values (pull out tests) on all re-roofing projects to verify the suitability of decking to accept a mechanically fastened insulation system.

- C. Examine surfaces for inadequate anchorage, low areas that will not drain properly, foreign material, ice, wet insulation, unevenness or any other defect that would prevent the proper execution and quality application of the FiberTite Induction Welded Roofing Systems as specified.
- **D.** Prepared substrate shall be smooth, dry, free of debris, and/or any other irregularities that would interfere with the proper installation of the FiberTite Induction Welded Roofing Systems.
- E. Do not proceed with any part of the application until all defects and preparation work have been corrected and complete.
- F. Adhesives will not bond to wet, damp or inadequately cured lightweight insulating concrete or poured structural concrete.

3.3 SUBSTRATE PREPARATION (NEW CONSTRUCTION)

A. Steel Deck

- 1. Steel decking shall conform to Factory Mutual (FM) guidelines for Class-1 insulated steel deck construction.
- 2. Steel decking shall be constructed of a minimum 22-gauge cold rolled steel sheets with factory G-90 galvanized coating.
- **3.** Panel profiles (ribs) shall be formed to minimize deflection and provide suitable strength and integrity to support anticipated structural live and dead loads.
- 4. Steel decking shall be installed in compliance with specified design criteria and local building code requirements.
- 5. Steel decking that is less than 22-gauge may be considered for application by Seaman Corporation. Fastener withdrawal tests shall be performed on all non-FM Approved steel decking, (decking less than 22-gauge) to determine suitability and appropriate fastener patterns and densities for mechanical attachment of the new components of the FiberTite Induction Welded Roofing Systems.

B. Structural Concrete (Poured and/or Pre-cast)

- 1. Decking shall be installed in strict conformance with industry standards, practices and/or pre-cast panel manufacturer's installation requirements.
- 2. Decking shall be installed to provide positive slope and subsequent positive drainage of the new FiberTite Induction Welded Roofing Systems.
- 3. Finished decking shall be properly cured and dried prior to the installation of approved insulation.
- 4. Finished surface(s) to receive new roof system shall be smooth and level without significant surface depressions or irregularities. Camber differentials greater than 3/16" must be leveled using a cementitious grout.
- 5. Finished surfaces shall be free of moisture, dust, loose debris and any other irregularities that may hinder the proper performance of the new FiberTite Induction Welded Roofing Systems.

C. Wood

- Wood decking shall conform to Factory Mutual (FM) guidelines for Class-1 impregnated wood decking. FM Class 1 decking consists of a minimum 2"-thick wood plank or minimum ³/₄" plywood.
- 2. Wood decking that is less than ³/₄" will be considered for application by Seaman Corporation. Fastener withdrawal tests shall be performed on all non-FM Approved wood decking (wood plank less than 2" thick or plywood less than ³/₄" thick) to determine suitability and appropriate fastener patterns for the components of the new FiberTite Induction Welded Roofing Systems.

- 3. Wood decking shall be sound, well-seasoned or kiln-dried and of proper thickness to accommodate design loads (including wind up-lift) according to specified design criteria and/or local building code requirements.
- 4. Wood decking should be installed to provide positive slope and subsequent positive drainage of the new FiberTite Induction Welded Roofing Systems.

3.4 SUBSTRATE PREPARATION (RE-ROOFING)

A. General

- 1. Roofing Contractor shall inform the building owner/owner representative of any issues in regard to the condition and structural integrity of the existing decking.
- 2. The building owner/owner representative shall make and be responsible for the determination as to the proper method of treatment and/or replacement.
- **3.** Re-roofing applications require fastener withdrawal tests to substantiate proposed attachment patterns for the new mechanically fastened insulation systems and/or membranes.
- 4. Re-roofing applications that require modification to the deck and/or insulation system should be installed to provide positive slope and subsequent positive drainage of the new FiberTite Induction Welded Roofing Systems.
- 5. All terminations of the FiberTite Induction Welded Roofing Systems must be constructed to prevent water from penetrating behind or beneath the new roofing system. This includes water from above, beside, below and beneath the new system.

B. Removal of Existing Roof System(s)

- 1. Remove all existing roofing material(s), insulation, flashing, metal and deteriorated wood blocking and legally dispose off-site.
- 2. Remove only enough roofing to accommodate the day's work and ensure the exposed area can be made 100% watertight at the end of the day or first sign of inclement weather.

C. Steel and Wood Decks

- 1. All rotted and/or deteriorated decking shall be removed and replaced with like kind.
- 2. Areas of structurally acceptable steel decking exhibiting slight surface rust shall be properly cleaned, primed and painted prior to installing the approved insulation.
- 3. All decking shall be inspected for proper attachment and excessive deflection that would compromise the uplift performance of the new FiberTite Induction Welded Roofing System.
- 4. Attachment and deflection deficiencies shall be repaired and brought into compliance with current, local building code requirements.

D. Concrete

- 1. Deteriorated decking shall be repaired and/or replaced with appropriate materials according to standard industry regulations and practices.
- 2. Repair any depressions and/or areas where reinforcing has become exposed.
- 3. When new insulation system is to be installed using an approved adhesive.

- 4. Cracks and or camber differentials greater than 3/16" shall be repaired using an appropriate cementitious grout or fill, and feathered to promote a smooth transition.
- 5. All surface irregularities shall be leveled to ensure complete contact with the decking for insulation bonded in hot asphalt or approved adhesives.
- 6. Where insulation is to be mechanically attached, camber differentials and/or surface irregularities of up to ¹/₂" shall be acceptable.

3.5 WOOD NAILERS

- A. Install treated lumber at the same heights as insulation layer or adjacent construction $\pm 1/4$ " continuous treated wood nailers are to be installed at all perimeters, around roof projections and penetrations as shown in approved details.
- **B.** Where wood nailers are installed directly on the substrate, the substrate shall be carefully examined to confirm that the entire area provides a suitable fastening surface. All defects shall be repaired by the appropriate trade prior to installation.
- **C.** Nailers shall be at least 3¹/₂" wide and 1¹/₂" high and installed and anchored in such a manner to resist a force of 250 lbs per linear foot of wood blocking in any direction.
- **D.** Nailers along parapets, curbs and expansion joints are recommended for insulated decking. Consult FiberTite Construction Details or FTCS for optional/alternate membrane termination/securement methods.

3.6 BASE SHEET

A. General

- 1. Approved base sheet, when required or specified, shall be applied only to properly prepared and pre-approved substrates.
- 2. Install no more than can be covered or made 100% watertight during the same working day.
- **3.** Field pull-out tests must be performed for mechanically attached base sheets to determine fastener withdrawal performance.
- 4. Base sheets shall be installed starting at the low point of the roof deck.
- 5. Base sheet shall be side lapped, a minimum of 3", and properly shingled to shed water.

B. Mechanically Attached Base Sheet

- 1. All base ply fasteners and stress plates for the mechanical attachment of base sheets shall be provided by Seaman Corporation.
- 2. For 1-90 attachment, approved base sheet is secured to the deck in the field of the roof, with FiberTite Fasteners, spaced a maximum of 7" on center through the minimum 3" side laps and staggered at a maximum 7" on center in two rows within the field of the sheet.
- 3. The number of fasteners securing the base sheet shall be increased over the field spacing by 70% in the perimeter and 100% in the corners of the roof area.
- 4. Fastening increases can be obtained by adding rows of fasteners and/or additional fasteners along each row.

3.7 ROOF INSULATION

A. General

- 1. Roof insulation shall be installed where by the long dimension of the board(s) run in parallel alignment and the short dimensions are staggered.
- 2. Insulation shall be installed with minimum joint dimensions and shall be tightly butted where possible. Maximum joint widths shall be 3/8". Damaged corners shall be cut out and replaced with an insulation piece a minimum of 12" x 12" pieces that are cut from larger panels and are smaller than one square foot are not acceptable.
- 3. Install no more than can be covered during the same working day.
- 4. Taper roof insulation to drain sumps using tapered edge strips. If an insulation layer is 1½" or less, taper 12" from the drain bowl. If insulation thickness exceeds 1½", taper 18" from the drain bowl. All taper boards or pieces must be adhered or mechanically fastened with a minimum of two fasteners per board.
- 5. When a cover board and/or multiple layers are installed each layer shall be offset from the previous layer a minimum of 12" on center.
- 6. At the end of each working day, provide a watertight cover on all unused insulation as to avoid moisture penetration.

B. Induction Welded Insulation Attachment – Plate Installation

- 1. Insulation shall be applied to and installed over properly prepared and pre-approved substrates, free of any debris, dirt, grease, oil or moisture.
- 2. All fasteners and FTR IW stress plates for the mechanical attachment of insulation and/or cover board materials and subsequent induction bond of FiberTite Roofing Membrane shall be FTR Fasteners as provided by Seaman Corporation.
- 3. All fasteners and stress plates shall be Factory Mutual Research approved for mechanical attachment of insulation and comply with FM Standard 4470 for corrosion resistance.
- 4. Install IW plates in a straight grid pattern using chalk lines. Proper plate layout will improve welding effectiveness.
- 5. General 1-90 attachment for insulation/cover board/membrane in the field of the roof requires one fastener and stress plate per 6 ft^2 of insulation.
- 6. Perimeter areas require a fastener tributary area decrease that is no greater than 60% of the field tributary per fastener.
- 7. Corner areas require a fastener tributary area decrease that is no greater than 40% of the field tributary per fastener.
- 8. Fasteners shall be installed flush with the substrate and not overdriven to the point of promoting plate deformation.
- 9. Fasteners shall be installed using depth sensing tool attachments to ensure proper installation.

3.8 INSTALLATION OF FIBERTITE MEMBRANE(S)

A. Quality Control

- 1. It is the responsibility of the roofing contractor to initiate and maintain a Quality Control (QC) program to govern all aspects of the installation of the FiberTite Induction Welded Roofing Systems.
- 2. The project foreman and or supervisor will be responsible for the daily execution of the QC program, which will include, but is not limited to, the supervision, inspection and probing of all heat welded seams and induction welded plates incorporated within the FiberTite Induction Welded Roofing Systems.
- **3.** If inconsistencies in the quality of the application of the composite, membrane and/or welds are found, all work shall cease until corrective actions are taken to ensure the continuity the installation.

B. General

- 1. Work shall be coordinated to ensure that sequencing of the installation promotes a 100% watertight installation at the end of each day.
- 2. All FiberTite Induction Welded Roofing Systems shall be designed utilizing and determined to be in compliance with the procedures outlined within the current publication of ASCE Standard 7. Alternative designs may be determined using the criteria within Factory Mutual Research Loss Prevention Data.
- 3. A FiberTite Induction Welded Roofing System may utilize either conventional roll goods or custom pre-welded panel rolls.
- 4. Restrictions regarding outside ambient air temperature are relative only to the exposure limits of the workers and/or adhesives when necessary.
- 5. When using adhesives outside ambient air temperature shall be above 40°F. Curing or drying time of the adhesive will be affected by ambient temperatures and must be taken into consideration when determining flashing lengths.
- 6. Humidity can affect the drying time of solvent borne adhesives and/or cause condensation to form on the newly applied adhesive.
- 7. No moisture may be present on the adhesive(s) prior to mating or application of FiberTite membranes.
- 8. FiberTite Induction Welded Roofing Systems shall only be installed over properly prepared and sound substrates, free from excessive surface roughness, dirt, debris and moisture.

C. FiberTite Membrane Installation

- 1. Unroll and position the FiberTite membrane and/or custom panel onto the properly prepared substrate, over the previously installed FTR IW plates.
- 2. Install the membrane in a flat, relaxed position avoiding excess wrinkles and stretching.
- 3. Adjoining rolls shall overlap a minimum of 2", properly shingled with the flow of water wherever possible.
- 4. Stager the factory seams in custom rolls to prevent adjacent factory welds from falling on top of one another.
- 5. The field membrane shall be properly affixed to wood blocking or restrained in an approved manner at all roof perimeters, walls, expansion joints, curbs and penetrations having any one dimension greater than 24" in length. Do not use FTR IW plates for transitional attachment. (See Current FiberTite Construction Details)

D. Welding

1. General

- a. All field seams exceeding 10' in length shall be welded with an approved automatic welder.
- b. All field seams must be clean and dry prior to initiating any field welding.
- c. Remove foreign materials from the seams (dirt, oils, etc.) with MEK or authorized alternative.
- d. Do not allow cleaning solvents to come in contact with the Kynar top finish when using FiberTite Brite. Aggressive solvents will either mar or completely remove the top finish.
- e. Use clean white cotton cloths and allow approximately five minutes for solvents to dissipate before initiating the automatic welder. Do not use denim or synthetic rags for cleaning.
- f. Contaminated areas within a membrane seam will inhibit proper welding and will require a membrane patch.

- g. All welding shall be performed only by qualified personnel to ensure the quality and continuity of the weld.
- h. Keep the bottom of the induction tool and cooling magnets clean.
- Continuous operation of the induction welding process can promote overheating of the cooling magnets.
 Periodically cool the magnets using clean water to prevent melting and/or scarring of the FiberTite membrane.
- j. Follow the Induction Welder Tool manufacturer's recommendations for periodic cleaning and maintenance for the equipment.

2. Hot Air Hand Welding

- a. The lap or seam area of the membrane may be intermittently tack welded to hold the membrane in place.
- b. The back interior edge of the membrane shall be welded first, with a thin, continuous weld to concentrate heat along the exterior edge of the lap during the final welding pass.
- c. The nozzle of the hand held hot air welder shall be inserted into the lap at a 45° angle to the lap. Once the polymer on the material begins to flow, a hand roller shall be use to apply pressure at a right angle to the tip of the hand welder. Properly welded seams shall utilize a 1½" wide nozzle, to create a homogeneous weld, a minimum of 1½" in width.
- d. Smaller nozzles may be used for corners, and other field detailing, maintaining a minimum 1" weld.

3. Automatic Hot Air Machine Welding

- a. Proper welding of the FiberTite Membrane can be achieved with a variety of automatic welding equipment. Contact FTCS for specific recommendations.
- b. Follow all manufacturer instructions for the safe operation of the automatic welder.
- c. Follow local code requirements for electric supply, grounding and surge protection.
- d. The use of a dedicated, portable generator is highly recommended to ensure a consistent electrical supply, without fluctuations that can interfere with weld consistency.
- e. Properly welded seams shall utilize a 1¹/₂" wide nozzle, to create a homogeneous weld, a minimum of 1¹/₂" width.

4. Induction Welding

- Calibrate the induction welding tool by making test welds with the FiberTite membrane and the IW stress plates. Make test welds using variable settings on the welder and then performing peel tests to examine continuity of the weld to the plate.
- b. The lowest energy setting that creates the most comprehensive and continuous bond is the preferred setting.
- c. All membrane shall be cleaned and dry prior to induction welding.
- d. Immediately upon completion of the induction weld cycle at each stress plate, place the cooling magnet directly centered over the welded membrane/plate assembly.
- e. Repeat the welding and magnet cooling process for each and every IW plate in the installation assembly.

E. Inspection

 The job foreman and/or supervisor shall initiate daily inspections of all completed work which shall include, but is not limited to the probing of all field welding with a dull pointed instrument to assure the quality of the application and ensure that any equipment or operator deficiencies are immediately resolved.

- 2. Ensure that all aspects of the installation (sheet layout, attachment, welding, flashing details, etc.) are in strict accordance with the most current FiberTite Roofing Systems Specifications and Details.
- **3.** Excessive patching of field seams because of inexperienced or poor workmanship will not be accepted at time of Final Inspection for Warranty Acceptance.
- 4. Any deviation from pre-approved specifications and/or details requires written authorization from the FTCS prior to application to avoid any warranty disqualification.
- 5. It is the contractor, job foreman, and supervisor and/or quality control personnel to perform a final self inspection on all seams prior to requesting the inspection for warranty issuance by the FTCS.

3.9 FLASHING

- A. Clean all vents, pipes, conduits, tubes, walls and stacks to bare metal. All protrusions must be properly secured to the roof deck with approved fasteners. Remove and discard all lead, pipes and drain flashing. Flash all penetrations according to approved details.
- B. Remove all loose and/or deteriorated cant strips and flashing.
- C. Flash all curbs, parapets and interior walls in strict accordance with approved FiberTite details.
- **D.** All flashing shall be adhered to properly prepared, approved substrate(s) with either FTR 190e, FTR-490 adhesive or FTR-201 mastic applied in sufficient quantity to ensure total adhesion.
- **E.** The base flashing of all membrane flashing shall extend out on to the plane of the deck, beyond the wood nailers to a maximum width of 8".
- F. Vertical flashing shall be terminated no less than 8" above the plane of the deck with approved termination bar and counterflashing or metal cap flashing.
- **G.** When using FTR-201 as the adhesive, vertical wall flashing termination shall not exceed 40" without supplemental mechanical attachment of the flashing between the deck and the termination point of the flashing.
- **H.** Complete all inside and outside corner flashing details with FiberTite preformed corners or an approved field fabrication detail.
- I. Probe all seams with a dull, pointed probe to ensure the weld has created a homogeneous bond.
- **J.** Install penetration accessories in strict accordance with approved details. Ensure penetration accessories have not impeded in any way the working specification. (Refer to the related trade for the technical specification).

3.10 METAL FLASHING

- A. All perimeter edge details are to be fabricated from FiberClad Metal or utilize a prefabricated FiberTite Fascia System.
- **B.** Ensure all fascia extend a minimum of 2" lower than the bottom of the wood nailers.
- C. Fasten all metal flashing to wood nailers or approved substrate with approved fasteners 8" on center.
- **D.** Break and install FiberClad metal in accordance with approved details, ensuring proper attachment, maintaining ¹/₂" expansion joints and the installation of a minimum 2" bond breaker tape prior to sealing the joint.
- **E.** Solidly weld FiberClad expansion joints with a 6" strip of FiberTite membrane welded to the FiberClad, covering the bond breaker tape (cover plates are optional).

F. Roof Drains

- 1. Flash all roof drains in accordance with FiberTite roof drain details.
- 2. Replace all worn or broken parts that may cut the FiberTite membrane or prevent a watertight seal. This includes the clamping ring and strainer basket.
- 3. Replace all drain bolts or clamps used to hold the drain compression ring to the drain bowl.
- 4. FiberTite non-reinforced 60 mil membrane shall be used for flashing the drain assembly. Drain assemblies and basins or sumps must be free of any asphalt or coal tar pitch residue prior to installation.
- 5. The drain target sheet should be sized and installed to provide for a minimum of 12" of exposed 60 mil on all sides of the drain.

G. Pitch Pans

- 1. Every reasonable effort shall be made to eliminate the need for pitch pans including the removal of all existing pans. Contact FTCS for specific design alternatives and recommendations.
- 2. In the event of no alternative, fabricate pitch pans from Fiber Clad metal, installed in accordance with FiberTite details, ensuring proper attachment, maintaining a minimum of 2" clearance around the penetration.
- **3.** Pitch pans shall be filled with non-shrinking grout to within 1" of the top of the pan. Allow the grout to dry and fill remainder of the pan with FTR-SL1 pourable sealant.
- 4. Pitch pans and the sealant will require periodic maintenance by the building owner's maintenance personnel.
- 5. Pitch pans are maintenance items and shall not be considered as part of the FiberTite warranty.

3.11 EXPANSION JOINTS

- A. Flash all expansion joints in accordance with authorized details. Fasten all expansion joint material according to FiberTite specifications. Ensure the expansion material has sufficient material to expand to the widest point in expansion without causing undue stress on the expansion joint material.
- **B.** If the expansion joint is a pre-formed system, the manufacturer, description and a drawing illustrating the method of installation must be included when the (FTR-PIN) is submitted.

3.12 SEALANTS

- **A.** Apply authorized sealant(s) to all surface mounted reglets and per project requirements. Sealant(s) are to shed water. Follow all manufacturer's instructions and installation guides.
- **B.** Use primer when recommended by the manufacturer.
- C. Sealants will require periodic maintenance by the building owner's maintenance personnel.

3.13 TEMPORARY SEALS

- **A.** At the end of each working day or at the sign of rain, install temporary, 100% watertight seal(s) where the completed new roofing adjoins the uncovered deck or existing roof surface.
- **B.** The authorized roofing contractor shall create and maintain the temporary seal in such a manner to prevent water from traveling beneath the new and/or existing roof system.
- C. The use of plastic roofing cement is permissible when sealing to an existing built up roof.

- **D.** If water is allowed to enter beneath the newly completed roofing, the affected area(s) shall be removed and replaced at no additional expense to the building owner.
- E. Prior to the commencement of work, cut out and remove all contaminated membrane, insulation, roof cement or sealant and properly dispose off site.

3.14 WALKWAYS

A. FiberTite walkways and protection pads shall be installed at staging areas for rooftop equipment maintenance or areas subject to regular foot traffic.

B. Walkway Installation

- 1. Roofing membrane to receive walkway material shall be clean and dry.
- 2. Cut and position the FiberTite walkway material as directed by the specifications or agreement.
- **3.** Hot air weld the entire perimeter of the walkway to the previously cleaned FiberTite roofing membrane. Avoid excessive heating of the walkway material to prevent scorching the underlying roofing membrane.

C. Protection Pad Installation

- 1. Roofing membrane to receive walkway material shall be clean and dry.
- 2. Prior to installing the FiberTite protection pads (1/4" x 2' x 4'), weld a 6" x 6" strip of FiberTite membrane to each of the four corners of the back side of the pad. Position the strips in such a way that they overhang the edge of the pad a minimum of 2" around the 90° corner.
- **3.** Position the FiberTite protection pads as directed by the specifications or agreement and weld the visible portion of the previously applied stripping to the FiberTite roofing membrane.

3.15 LIGHTNING PROTECTION

- **A.** The installation of lightning protection must be coordinated with the authorized FiberTite roofing contractor, certified lightning contractor and the building owner.
- **B.** The lightning protection must be installed in such a manner that base plates, air terminals and cables do not penetrate the roofing membrane without the use of pre-approved flashing details.
- C. Cables and air terminals may be attached to the membrane using base plates and FTR101 Sealant and by welding intermittent strips of FiberTite membrane at 4' intervals cables to the FiberTite roofing. Contact FTCS for specific adhesive recommendations.
- **D.** Recommendations regarding the selection of adhesives or alternative affixing of lightning protection systems to the FiberTite membrane does not in any way imply a warranty covering their performance or ability of the adhesives to remain affixed to the FiberTite membrane.

3.16 COMPLETION

- A. Remove any and all debris, excess materials and scrap of any kind from the roof and surrounding premises prior to demobilization.
- **B.** Inspect all field welds, detailing and terminations to ensure a 100% watertight installation.

3.17 WARRANTY INSPECTION

- **A.** Upon completion of the project, the authorized roofing contractor shall complete and submit the FiberTite Project Completion Notice to FTCS.
- **B.** Upon receipt of the notice of completion, a FTCS representative will schedule an inspection with a representative of the authorized roofing contractor to thoroughly review the installation and verify compliance with Seaman Corporation specifications.
- **C.** Any corrections or modifications necessary for compliance with the specifications and acceptance for warranty (punch list) will be noted on the Final Inspection for Warranty Form.
- **D.** Upon completion of all punch list items and final acceptance of the installation, a warranty as authorized by the approved Seaman Corporation/FiberTite Pre-Installation Notice will be issued.

END OF SECTION FTR-IW GS08/17